



LEDVANCE USER MANUAL

GRID-CONNECTED PV INVERTER

LT-3K F1

LT-6K F1

LT-9K F1

LT-4K F1

LT-7K F1

LT-10K F1

LT-5K F1

LT-8K F1

LT-12K F1

LEDVANCE.COM



LEDVANCE

CONTENTS

INTRODUCTION	2
Appearance introduction	2
Labels description	2
Parts list	3
Product handling requirements	4
SAFETY WARNINGS AND INSTRUCTIONS	4
Safety signs	4
Safety instructions	5
Notes for using	5
OPERATION INTERFACE	6
Interface view	6
Status indicator	6
Buttons	6
LCD display	7
PRODUCT INSTALLATION	7
Select installation location	7
Installations tools	9
Inverter installation	10
ELECTRICAL CONNECTION	12
PV module selection	12
DC input terminal connection	12
AC input terminal connection	14
The connection of the ground line	17
Max.over current protection device	18
Inverter monitoring connection	18
Installation of datalogger	19
Configuration of datalogger	19
STARTUP AND SHUTDOWN	20
Start up the inverter	20
Inverter shutdown	20
Anti-PID function (optional)	20
ZERO-EXPORT FUNCTION VIA ENERGY METER	21
Multiple strings and parallel connection meters	21
Use of zero-export function	30
Notes while using zero export function	31
GENERAL OPERATION	32
The initial interface	35
Submenus in the main menu	36
System param setting	38
Protect param setting	39
Comm. param setting	41

CONTENTS

REPAIR AND MAINTENANCE	42
ERROR INFORMATION AND PROCESSING	43
Error code	43
SPECIFICATION	47
EU DECLARATION OF CONFORMITY	50


ABOUT THIS MANUAL

The manual mainly describes the product information, guidelines for installation, operation and maintenance. The manual cannot include complete information about the photovoltaic (PV) system.

How to use this manual

Read the manual and other related documents before performing any operation on the inverter. Documents must be stored carefully and be available at all times. Contents may be periodically updated or revised due to product development. The information in this manual is subject to change without notice. The latest manual can be acquired via www.ledvance.com

Photovoltaic grid-connected system





INTRODUCTION






Appearance introduction

On-grid Inverter can convert solar panel DC power into AC power which can directly input to the grid. Its appearance is shown below. These models contain LT-3K F1, LT-4K F1, LT-5K F1, LT-6K F1, LT-7K F1, LT-8K F1, LT-9K F1, LT-10K F1, LT-12K F1.

The following is collectively referred to as "inverter".















Labels description

Label	Description
	Caution, risk of electric shock symbol indicates important safety instructions, which if not correctly followed, could result in electric shock.
	The DC input terminals of the inverter must not be grounded.
	CE mark of conformity.
	Please read the instructions carefully before use.
	Symbol for the marking of electrical and electronics devices according to Directive 2002/96/EC. Indicates that the device, accessories and the packaging must not be disposed as unsorted municipal waste and must be collected separately at the end of the usage. Please follow Local Ordinances or Regulations for disposal or contact an authorized representative of the manufacturer for information concerning the decommissioning of equipment.

INTRODUCTION

Parts list


Please check the following table, to see whether all the parts are included in the package:

 <p>Grid-tied PV string inverter ×1</p>	 <p>Wall mounting bracket ×1</p>	 <p>Mounting stainless steel screws M4×12 ×5</p>
 <p>AC power connectors ×1</p>	 <p>DC + /DC- plug connectors including metal terminal ×N</p>	 <p>Stainless steel anti-collision bolt M6×60 ×4</p>
 <p>*Sensor clamp (optional) ×3</p>	 <p>Meter (optional) ×1</p>	 <p>HJA4 core wire female connector - screw crimp ×1</p>
 <p>Quick installation guide ×1</p>	 <p>Solar photovoltaic connector special spanner ×1</p>	 <p>Datalogger (optional) ×1</p>

INTRODUCTION

Product handling requirements

Lift the inverter out of the packing box and transport it to designated installation location.



transport



CAUTION:

Improper handling may cause personal injury!

- Arrange an appropriate number of personnel to carry the inverter according to its weight, and installation personnel should wear protective equipment such as anti-impact shoes and gloves.
- Placing the inverter directly on a hard ground may cause damage to its metal enclosure. Protective materials such as sponge pad or foam cushion should be placed underneath the inverter.
- Move the inverter by one or two people or by using a proper transport tool.
- Move the inverter by holding the handles on it. Do not move the inverter by holding the terminals.

Safety warnings and instructions

Improper use may result in potential electric shock hazards or burns. This manual contains important instructions that should be followed during installation and maintenance. Please read these instructions carefully before use and keep them for future reference.

Safety signs

Safety symbols used in this manual, which highlight potential safety risks and important safety information, are listed as follows:



WARNING:

Warning symbol indicates important safety instructions, which if not correctly followed, could result in serious injury or death.



SHOCK HAZARD:

Caution, risk of electric shock symbol indicates important safety instructions, which if not correctly followed, could result in electric shock.



SAFETY HINT:

Note symbol indicates important safety instructions, which if not correctly followed, could result in some damage or the destruction of the inverter.



HIGH TEMPERATURE HAZARD:

Caution, hot surface symbol indicates safety instructions, which if not correctly followed, could result in burns.

SAFETY WARNINGS AND INSTRUCTIONS

Safety instructions

Lift the inverter out of the packing box and transport it to designated installation location.

**WARNING:**

Electrical installation of the inverter must conform to the safety operation rules of the country or local area.

**WARNING:**

Inverter adopts non-isolated topology structure, hence must insure DC input and AC output are electrical isolated before operating the inverter.

**SHOCK HAZARD:**

Prohibit disassembling inverter case, there existing shock hazard, which may cause serious injury or death, please ask qualified person to repair.

**SHOCK HAZARD:**

When PV module is exposed to sunlight, the output will generate DC voltage. Prohibit touching to avoid shock hazard.



5min

SHOCK HAZARD:

While disconnect the input and output of the inverter for maintenance, please waits for at least 5 mins until the inverter discharge the remnant electricity.

**HIGH TEMPERATURE HAZARD:**

Local temperature of inverter may exceed 80 °C while under operating. Please do not touch the inverter case.


Notes for using

The three phase string power inverter is designed and tested under related safety regulations. It can ensure the personal safety of the user. But as a electric device, it may cause shock or injury by incorrect operation. Please operate the unit under below requirements:

- Inverter should be installed and maintained by qualified person under local standard regulations.
- Must disconnect the AC side first, then disconnect DC side while doing installation and maintenance, after that, please wait at least 5 mins to avoid getting shocked.
- Local temperature of the inverter may exceed 80 °C while under operating. Do not touch to avoid getting injured.
- All electrical installation must be in accord with local electrical standards, and after obtaining the permission of the local power supply department, the professionals can connect the inverter to the grid.
- Please take appropriate anti-static measure.
- Please install where children can not touch.
- The steps to start the inverter:
 - 1) Switch on the AC side circuit breaker,
 - 2) Switch on the DC side circuit breaker of the PV panel.
 - 3) Turn on the DC switch of the inverter.
- The steps to stop the inverter:
 - 1) Switch off the AC side circuit breaker,
 - 2) Switch off the DC sidecircuit breaker of the PV panel.
 - 3) Turn off the DC switch of the inverter.
- Don't insert or remove AC and DC terminals when the inverter is in normal operation.
- The DC input voltage of the inverter must not exceed the maximum value of the model.

OPERATION INTERFACE

Interface view



Front panel display

Status indicator


There are four LED status indicator lights in the front panel of the inverter.

Indicator	Status	Explanation
● DC	on	Inverter detects DC input
	off	Low DC input voltage
● AC	on	Grid Connected
	off	Grid Unavailable
● NORMAL	on	Under normal operating
	off	Stop operating
● ALARM	on	Detected faults or report faults
	off	Under normal operating

Buttons

There are four keys in the front panel of the Inverter (from left to right): Esc, Up, Down and Enter keys. The keypad is used for:

- Scrolling through the displayed options (the Up and Down keys);
- Access to modify the adjustable settings (the Esc and Enter keys).



OPERATION INTERFACE

Lcd display

The two-line Liquid Crystal Display (LCD) is located on the front panel of the Inverter, which shows the following information:


- Inverter operation status and data; Service messages for operator;
- Alarm messages and fault indications.

Select installation location

To select a location for the inverter, the following criteria should be considered:

WARNING: Risk of fire

- Do not install the inverter in areas containing highly flammable materials or gases.
- Do not install the inverter in potentially explosive atmospheres.
- Do not install in small closed spaces where air can not circulate freely. To avoid overheating, always make sure the flow of air around the inverter is not blocked.
- Exposure to direct sunlight will increase the operational temperature of the inverter and may cause output power limiting. It is recommended that inverter installed to avoid direct sunlight or raining.
- To avoid overheating ambient air temperature must be considered when choosing the inverter installation location. It is recommended that using a sun shade minimizing direct sunlight when the ambient air temperature around the unit exceeds 104 °F/40 °C.




PRODUCT INSTALLATION

- Install on a wall or strong structure capable of bearing the weight.
Install vertically with a maximum incline of $+15^\circ$. If the mounted inverter is tilted to an angle greater than the maximum noted, heat dissipation can be inhibited, and may result in less than expected output power.
- If install more than one inverter, must leave at least 500 mm gap between each inverter. And two adjacent inverters are also separated by at least 500 mm. And must install the inverter at the place where children cannot touch.
- Consider whether the installation environment is helpful to see the inverter LCD display and indicator status clearly.
- Must offer a ventilate environment if inverter installed in the airtight house.




SAFETY HINT:

Do not place or store any items next to the inverter.



PRODUCT INSTALLATION



Installations tools

Installation tools can refer to the following recommended ones. Also, use other auxiliary toolson site.


Tool specification

Protective goggles	Anti-dust mask	Earplugs	Work gloves	Work shoes	Utility knife	Slotted screwdriver
Cross screwdriver	Percussion drill	Pliers	Marker	Level	Rubber hammer	Socket wrenches set
Anti-static wrist strap	Wire cutter	Wire stripper	Hydraulic pliers	Heat gun	Crimping tool4-6 mm ²	Solar connector wrench
Multimeter ≥1100 Vdc	RJ45 crimping plier	Cleaner				

PRODUCT INSTALLATION

Inverter Installation


The inverter is designed according to the wall mounted type installation, please use the wall mounted (the brick wall of the expansion bolt) when installing.




PRODUCT INSTALLATION

Procedure shows below:

- Locate on the appropriate wall according to the bolt position on the mounting bracket, then mark the hole. On the brick wall, the installation must be suitable for the expansion bolt installation.



- Ensure that the position of the installation holes on the wall is in accordance with the mounting plate, and the mounting rack is vertically placed.
- Hang the inverter to the top of the mounting rack and then use the M4 screw in the accessory to lock inverter heat sink to the hanging plate, to ensure that the inverter will not move.



ELECTRICAL CONNECTION

Pv module selection:

When selecting proper PV modules, please be sure to consider below parameters:

- Open circuit Voltage (Voc) of PV modules not exceeds max. PV array open circuit voltage of inverter.
- Open circuit Voltage (Voc) of PV modules should be higher than min. start voltage.
- The PV modules used to connected to this inverter shall be class A rating certified according to IEC 61730.

Inverter model	SUN-3/4/5/6/7/8/9/10K/12K-F1
PV Input Voltage	600V (140 V - 1100 V)
PV Array MPPT Voltage Range	120 V - 1000 V
No.of MPP Trackers	2
No.of Strings per MPP Tracker	1+1

Dc input terminal connection

- Switch the Grid Supply Main Switch (AC) OFF.
- Switch the DC Isolator OFF.
- Assemble PV input connector to the inverter.



WARNING:

When using PV modules, please ensure the PV+ & PV- of solar panel is not connected to the system ground bar.




SAFETY HINT:

Before connection, please make sure the polarity of the output voltage of PV array matches the "DC+" and "DC-" symbols.




WARNING:

Before connecting inverter, please make sure the PV array open circuit voltage is within the 1100 V of the inverter.



DC+ male connector



DC- female connector

ELECTRICAL CONNECTION



SAFETY HINT:


Please use approved DC cable for PV system.

Cable type	Cross section (mm ²)	
	Range	Recommended value
Industry generic PV cable (model: PV1-F)	2.5 - 4.0 (12 -10 AWG)	2.5 (12 AWG)

DC Cable Specifications


The steps to assemble the DC connectors are listed as follows:

- Strip off the DC wire about 7 mm, disassemble the connector cap nut.




Disassemble the connector cap nut

- Crimping metal terminals with crimping pliers.



Crimp the contact pin to the wire


- Insert the contact pin to the top part of the connector and screw up the cap nut to the top part of the connector.



connector with cap nut screwed on

ELECTRICAL CONNECTION

– Finally insert the DC connector into the positive and negative input of the inverter.



DC input connection



WARNING:

Sunlight shines on the panel will generate voltage, high voltage in series may cause danger to life. Therefore, before connecting the DC input line, the solar panel needs to be blocked by the opaque material and the DC switch should be 'OFF', otherwise, the high voltage of the inverter may lead to lifethreatening conditions.



WARNING:

Please use its own DC power connector from the inverter accessories. Do not interconnect the connectors of different manufacturers. Max. DC input current should be 20 A. If exceeds, it may damage the inverter and it is not covered by LEDVANCE warranty.

Ac input terminal connection

Do not close the DC switch after the DC terminal is connected. Connect the AC terminal to the AC side of the inverter, the AC side is equipped with Three phase AC terminals that can be conveniently connected. Flexible cords are recommended for easy installation. The are as shown in Table below.



WARNING:


Prohibit using a single circuit breaker for multiple inverters, prohibit the connection of load between inverter circuit breakers.

Model	Cable CSA	Cable outer DIA	AWG	Breaker	Max. cable length
LT-3K F1	0.75 mm ²	2 - 3 mm	18	20 A / 400 V	Outside cable (3L + N + PE) 20 m
LT-4/5/6K F1	1.0 mm ²	3 - 4 mm	16	20 A / 400 V	
LT-7K F1	1.25 mm ²	3 - 4 mm	16	20 A / 400 V	
LT-8/9K F1	1.5 mm ²	3.5 - 4.5 mm	14	20 A / 400 V	
LT-10/12K F1	2.5 mm ²	4 - 5 mm	12	30 A / 400 V	

ELECTRICAL CONNECTION


The AC output connector is divided into three parts: matching socket, sleeve and sealingsleeve, the steps are as follows:

- Step 1: Remove the cable sealing ring and sleeve in sequence from the AC connector.
- Step 2: Use strippers to strip the protective sheath and insulation layer of the AC cable to the right length.



1. Matching socket 2. Sleeve 3. Sealing core 4. Sealing nut
AC connector structure

- Step 3: Insert the cable (L1,L2,L3,N,PE) into the sealing sleeve.




Strip AC cable



WARNING:

Be careful to distinguish the L1, L2, L3, N and PE of the AC cables.


- Step 4: Use the hexagon screwdriver, loosen the bolts of the socket in turn, and insert each cable core into the corresponding jack, and set each screw. The connection hole of AC connection terminal labeling is shown in Picture below.




AC connector hole pattern

ELECTRICAL CONNECTION

- Step 5: Set the sleeve and sealing ring in place.
- Step 6: Connect the terminals to the inverter as shown in picture below.




- Step 7: After connecting AC connector to grid port at the bottom of the machine, fix the protective sleeve to the joint position, and then fix it with screws.



INSTALLATION

The connection of the ground line

Good grounding is good for resisting surge voltage shock and improving EMI performance. Therefore, before connecting AC, DC and communication cables, you need to ground the cable firstly. For a single system, just ground the PE cable. For multiple machine systems, all PE cables of the inverter need to be connected to the same grounding copper platoon to ensure the equipoten-tial connection. The installation of the shell ground wire is shown as picture below. The external protective earthing conductor is made of the same metal as the phase conductor.



The installation of the shell ground wire

Model	Wire size	Cable (mm ²)	Torque value (Max.)
LT-3K F1	18 AWG	0.75 mm ²	8.5 Nm
LT-4/5/6K F1	16 AWG	1. mm ²	8.5 Nm
LT-7K F1	16 AWG	1.25 mm ²	8.5 Nm
LT-8/9K F1	14 AWG	1.5 mm ²	8.5 Nm
LT-10/12K F1	12 AWG	2.5 mm ²	8.5 Nm



WARNING:

Inverter has built-in leakage current detection circuit, the type A RCD can be connected to the inverter for protection according to the local laws and regulations. If an external leakage current protection device is connected, its operating current must be equal to 300 mA or higher, otherwise inverter may not work properly.

ELECTRICAL CONNECTION

Max.Over current protection device


In order to protect the inverter AC connection, it is recommended to install a circuit breaker to prevent overcurrent.

Inverter	Rated output voltage (V)	Rated output current (A)	Current for protection device (A)
LT-3K F1	220 / 230	4.6 / 4.4 A	20
LT-4K F1	220 / 230	6.1 / 5.8 A	20
LT-5K F1	220 / 230	7.6 / 7.3 A	20
LT-6K F1	220 / 230	9.1 / 8.7 A	20
LT-7K F1	220 / 230	10.7 / 10.2 A	20
LT-8K F1	220 / 230	12.2 / 11.6 A	20
LT-9K F1	220 / 230	13.7 / 13.1 A	20
LT-10K F1	220 / 230	15.2 / 14.5 A	30
LT-12K F1	220 / 230	18.2 / 17.4 A	30

Recommended current protector specifications

Inverter monitoring connection


Inverter has the function of wireless remote monitoring. The inverter with Wi-Fi function is equipped with Wi-Fi plug to connect the inverter and network. Wi-Fi plug's operation, installation, internet access, APP downloading and other processes are detailed in the instructions.



ELECTRICAL CONNECTION

Installation of datalogger

When installing the WiFi stick, tear off the sealing strip on the inverter. Insert the datalogger into the interface and fix it with a screw. The configuration of the datalogger needs to be performed after various electrical connections have been completed and the inverter DC power on. When the inverter is on the DC power, it is determined whether the datalogger is normally electrified (The LED light shines out of the shell) .



Configuration of datalogger

For the configuration of datalogger, please refer to illustrations of the datalogger.

STARTUP AND SHUTDOWN

Startup and shutdown

Before starting the inverter, make sure that the inverter can meet the following conditions, otherwise it may result in fire or damage to the inverter. In this case, we do not undertake any responsibility. At the same time, to optimize the system configuration, it is recommended that the two inputs be connected to the same number of photovoltaic modules.

- a). The maximum open circuit voltage of each set of photovoltaic modules shall not exceed 1100 Vdc under any conditions.
- b). Each input of the inverter better use the same type of photovoltaic module in series.
- c). Total output power of PV shall not exceed the maximum input power of inverter, each photovoltaic modules shall not exceed the rated power of each channel.

STARTUP AND SHUTDOWN

Start up the inverter

When starting up the three phase string inverter, should follow steps below:

- Starting switch on the AC breaker.
- Turn on the DC switch of the photovoltaic module, and if the panel provides sufficient starting voltage and power, the inverter will start.
- The inverter will first check the internal parameters and the grid parameters, while the liquid crystal will show that the inverter is self-checking.
- If the parameter is within acceptable range, the inverter will generate energy.


NORMAL indicator light is on.

Inverter shutdown

Must follow below steps while shutting down the inverter:

- Switch off the AC breaker.
- Wait for 30 seconds, turn off the DC switch (if any), or simply disconnect the DC input connector. The inverter will close the LCD and all LED within two minutes.

Anti-pid function (option)



The Anti-PID module repairs the PID effect of the PV module at night. The PID module always runs when connected to AC.

If maintenance is required and turn off the AC switch can disable the Anti-PID function.



WARNING:

The PID functionality is automatic. When the DC bus voltage is below 50 VDC, the PID module will create 450 VDC between the PV and ground. No control and equipment are required.





WARNING:

If you need to maintain the inverter, please turn off the AC switch first, then turn off the DC switch, and wait 5 minutes before you do other operations.


ZERO-EXPORT FUNCTION VIA ENERGY METER



Eastron SDM630-Modbus V2



Eastron meter




Connection diagram of eastron meter



WARNING:


In final installation, breaker certified according to IEC60947-1 and IEC 60947-2 shall be installed with the equipment.

ZERO-EXPORT FUNCTION VIA ENERGY METER





Eastron SDM630-Modbus V2



Connection diagram of eastron meter



ZERO-EXPORT FUNCTION VIA ENERGY METER



ZERO-EXPORT FUNCTION VIA ENERGY METER




ZERO-EXPORT FUNCTION VIA ENERGY METER

Name	Description	Range
Exp_Mode	AVG: average power of three phase is zero exported. MIN: phase with minimum load power is zero exported, while the other two phase may be in purchase mode.	AVG / MIN
CT_Ratio	CT ratio of power grid side meter when extern CT is applied.	1 - 1000
MFR	Manufacturer of the grid side meter. ModbusAddress of it should be set as 01.	EASTRON
Feedin	Percentage of the Feed in power exported to the grid.	0 - 110%
Shunt	Parallel mode. Set one inverter as Master, others are Slave. ONLY need to set the master, slave will follow the settings in the master.	OFF / Master / slave
Shunt QTY	Number of inverters in parallel	1 - 16
Generator	DG side meter function enable / disable	ON / OFF
G.CT	CT ratio of power DG side meter when extern CT is applied.	1 - 1000
G.MFR	Manufacturer of the DG side meter. Modbus address of it should be set as 02.	EASTRON
G.Cap	Capacity of the DG.	1 - 999 kW


Note: select meter option in run param and long press ENTER button to enter this meter setting page.

ZERO-EXPORT FUNCTION VIA ENERGY METER





Eastron SDM630-Modbus V2

Eastron meter





Eastron connection diagram (The pass-through table)

ZERO-EXPORT FUNCTION VIA ENERGY METER




Eastron connection diagram (The pass-through table)


ZERO-EXPORT FUNCTION VIA ENERGY METER




ZERO-EXPORT FUNCTION VIA ENERGY METER



Eastron SDM630MCT



Eastron meter



Connection diagram (Three-phase electricity)

ZERO-EXPORT FUNCTION VIA ENERGY METER

Use of zero-export function

When the connection is completed, the following steps should be referred to use this function:

- Turn on the AC switch.
- Turn on the DC switch, waiting for the inverter's LCD is turned on.
- Press Enter button on the LCD panel in the main interface into the menu options, select [parameter setting] to enter setup submenu, and then select [running parameters] as shown in picture below, at this time please input the default password 1234 through pressing the button [up down, enter] , enter the operation parameter setting interface.



System Param <<
Run Param

Parameter setting



Island Meter OFF
OFF<<

Meter switch

- Operate the button [up down], move setting cursor to energy meter and press the button [enter]. At this time you can turn on or turn off the energy meter by choosing [up down] button, please press [enter] button to confirm when setting done.
- Move the cursor to [OK], press [enter] to save the settings and exit the running parameters page, otherwise the settings are invalid.
- If set up successfully, you can return to the menu interface, and display the LCD to [home page] by press the [up down] button. If it displays [meter power XXW], the zero-export function setting is completed.



Meter Power:
20 W

Zero-export function via energy meter turn on

- Meter power XXW shows positive means grid is supplying the load, and no power fed into grid. If meter power shows negative, it means PV energy is being sold to grid or energy meter wiring connection has problem.
- After properly connection is done, wait for inverter starting. If the power of the PV array meets the current power consumption, the inverter will keep a certain output to counteract the power of the grid without backflow.

ZERO-EXPORT FUNCTION VIA ENERGY METER

Notes while using zero export function

Notes while using zero export function.



SAFETY HINT:

Under zero export mode we strongly recommend that the two PV arrays are formed by the same number of PV panels of the same size, which will make the inverter more responsive to limit the power.




SAFETY HINT:


While the utility power is negative and inverter has no output power, that means the orientation of the current sensor is wrong, please turn off the inverter and change orientation of the current sensor.

GENERAL OPERATION

During normal operation, the LCD shows the current status of the inverter, including the current power, total generation, a bar chart of power operation and inverter ID, etc. Press the Up key and the Down key to see the current DC voltage, DC current, AC voltage, AC current, inverter radiator temperature, software version number and WiFi connection state of the inverter.




GENERAL OPERATION



GENERAL OPERATION

*Note: These parameters will be available after the meter is connected successfully. Otherwise, it won't show.
 Attention: For running param detail on the LCD display, please refer to the official LEDVANCE website <https://www.ledvance.com>



GENERAL OPERATION

The initial interface

From the initial interface, you can check PV power, PV voltage, grid voltage, inverter ID, model and other information.

Power: 0 W
State: Standby

Power: 0 W
State: Com.Error

The initial interface

Press UP or Down, you can check inverter DC voltage, DC current, AC voltage, AC current and inverter temperature.

Total DC POWER:
0 W

PV input voltage and current information

PV1: 0.0 V 0.0 A
Power: 0 W

Load power

UA: 234 V 0.0 A
UB: 0 V 0.0 A

Grid voltage and current information

UC: 0V 0.0 A
Freq: 0.00 Hz

Grid voltage and frequency

E-Day : 0 Wh
E-Total : 134 kWh

PV generation

E-Day: Daily generation;
E-Total: Total generation.

21 - 05 - 2020
15 : 57 : 08

Time

Meter
Power: 0 W

Meter power

LoadEp: 0.00 kWh
Total : 0.00 kWh

Load consumption

LoadEp: Daily consumption;
Total: Total energy consumption.

GENERAL OPERATION

ImpEp: 0.00 kWh
Total : 0.00 kWh

Electrical energy

ImpEp: Daily energy purchased from grid;
Total: Total energy purchased from grid.

ExpEp: 0.00 kWh
Total : 0.00 kWh

Electrical energy

ExpEp: Daily energy sold to grid;
Total: Total energy sold to grid.

Submenus in the main menu

There are five submenus in the Main Menu.

Device information

You can see the LCD software VerA238 and control board software Ver1400. In this interface, there are parameters such as rated power communication addresses.

Device Info. <<
Fault Record

GL3000 SN-01
PF: 0.000

ID:2104149060
Inv1400

Inv1400
LcdA244

Device information

Fault record

It can keep eight fault records in the menu including time, customer can deal with it dependson the error code.

Device Info.
Fault Record <<

1 F35 220513 07
2 F35 220513 06

3 F35 220513 06
4 F35 220513 06

Fault record

GENERAL OPERATION

On/off setting

ON / OFF << Setup	Turn ON << Turn OFF
Turn ON OK << Cancel	Turn OFF OK << Cancel

ON/OFF setting

When the inverter is turned off, it stops working immediately, and go to standby mode and then will go to self-test program again. If it passed the self-test, it will start to work again.

Parameter setting

There are five submenus in the setup. Setting includes system param, run param, protect param, comm: param. All of these information for maintenance reference.

System Param << Run Param	Protect Param Comm. Param <<
--	---

Submenus of the parameter setup

GENERAL OPERATION

System param setting

System Param includes time set, language set, display set and factory reset.

Time Set << Language Set	Display Set Factory Reset <<
Factory Reset Set Restore <<	

System param

20200522 OK 08:11:21 Cancel	English << Polski
--	--

Time

English Nederland <<	Bright Delay << Delay time 05 s
---	--

Language

LCD screen settings

Delay time 05 s OK << Cancel	Factory Reset << Cancel
---	--

Delay time set

Reset to factory setting

I Confirm << Cancel
--

Set restore

GENERAL OPERATION

Protect param setting



WARNING:

Engineer Only.

We will set the param depends on the safety requirements, so customers don't need to reset it. The password is same as running param.

PassWord * * * *	GridStanderd << Advanced
Back <<	

Password

Braszil EN50549-1-PL <<	EN50549-1 IEC61727 <<
CUSTOM VDE4105 <<	VDE0126 Spain <<
CEI_0-21 G98 <<	G99 NBT32004-B <<
Australia-A Australia-B <<	Australia-C New Zealand <<
MEA PEA <<	Norway Switzerland <<
R25 OK Cancel <<	

Grid Standerd

GENERAL OPERATION

OverVolt Lv3
Point 240.0 V <<

OverVolt Lv3
Delay 1000 ms <<

OverVolt Lv2
Point 240.0 V <<

OverVolt Lv2
Delay 1000 ms <<

OverVolt Lv1
Point 240.0 V <<

OverVolt Lv1
Delay 1000 ms <<

UnderVolt Lv1
Point 235.0 V <<

UnderVolt Lv1
Delay 1000 ms <<

UnderVolt Lv2
Point 235.0 V <<

UnderVolt Lv2
Delay 1000 ms <<

UnderVolt Lv3
Point 235.0 V <<

UnderVolt Lv3
Delay 1000 ms <<

OverFreq Lv3
Point 52.00 Hz <<

OverFreq Lv3
Delay 1000 ms <<

OverFreq Lv2
Point 52.00 Hz <<

OverFreq Lv2
Delay 1000 ms <<

OverFreq Lv1
Point 52.00 Hz <<

OverFreq Lv1
Delay 1000 ms <<

UnderFreq Lv1
Point 48.00 Hz <<

UnderFreq Lv1
Delay 1000 ms <<

GENERAL OPERATION

UnderFreq Lv2 Point 48.00 Hz <<	UnderFreq Lv2 Delay 1000 ms <<
UnderFreq Lv3 Point 48.00 Hz <<	UnderFreq Lv3 Delay 1000 ms <<
Reconnection Vup 0.0 V <<	Reconnection Vdown 0.0 V <<
Reconnection Fup 0.00 Hz <<	Reconnection Fdown 0.00 Hz <<
OV 10 Minutes Enable OFF <<	OV 10 Minutes Point 0.0% <<
Point 0.0% Grid --- <<	OK Cancel <<

"CUSTOMI7Tn"

Please set the proper grid parameters according to the requirements of your current country's grid regulations. If you are not clear about it, please consult your installer.

Comm.Param setting

Address: 01 << BaudRate: 9600	Func: Meter Address1: 01
--	-------------------------------------

Comm. Param

REPAIR AND MAINTENANCE

String type inverter doesn't need regular maintenance. However, debris or dust will affect heat sink's thermal performance. It is better to clean it with a soft brush. If the surface is too dirty and affect the reading of LCD and LED lamp, you can use wet cloth to clean it up.



HIGH TEMPERATURE HAZARD:

When the device is running, the local temperature is too high and the touch can cause burns. Turn off the inverter and wait for it cooling, then you can clean and maintain.



SAFETY HINT:

No solvent, abrasive materials or corrosive materials can be used for cleaning any parts of the inverter.

ERROR INFORMATION AND PROCESSING

Inverter has been designed in accordance with international grid tied standards for safety, and electromagnetic compatibility requirements. Before delivering to the customer the inverter has been subjected to several tests to ensure its optimal operation and reliability.

ERROR INFORMATION AND PROCESSING

Error code

If there is any failure, the LCD screen will display an alarm message. In this case, the inverter may stop feeding energy into the grid. The alarm description and their corresponding alarm messages are listed Table below.

Error code	Description	Ongrid -three phase
F01	DC input polarity reverse fault	Check the PV input polarity.
F02	DC insulation impedance permanent fault	Check the grounding cable of inverter.
F03	DC leakage current fault	Hardly appear the code. Never ever happened so far.
F04	Ground fault GFDI	Check the solar panel output connection.
F05	Read the memory error	Failure in reading memory (EEPROM). Restart the inverter if the fault still exists, contact your installer or LEDVANCE service.
F06	Write the memory error	Failure in writing memory (EEPROM). Restart the inverter if the fault still exists, contact your installer or LEDVANCE service.
F07	GFDI blown fuse	Hardly appear the code. Never ever happened so far.
F08	GFDI grounding touch failure	Hardly appear the code. Never ever happened so far.
F09	IGBT damaged by excessive drop voltage	Hardly appear the code. Never ever happened so far.
F10	Auxiliary switch power supply failure	1. It tells the DC 12 V is not existed. 2.Restart the inverter, if the fault still exists, please contact your installer or LEDVANCE service.
F11	AC main contactor errors	Hardly appear the code. Never ever happened so far.
F12	AC auxiliary contactor errors	Hardly appear the code. Never ever happened so far.
F13	reserved	1.Loss of one phase or AC voltage detection part failure or relays not closed. 2.Restart the inverter, if the error still exists, please contact your installer or LEDVANCE service.
F14	DC firmware over current	Hardly appear the code. Never ever happened so far.
F15	AC firmware over current	1.The internal AC sensor or detection circuit on control board or connection wire may loose. 2.Restart the inverter, if the error still exists, please contact your installer or LEDVANCE service.
F16	GFCI (RCD) Ac leakage current fault	1.This fault means the average leakage current is over 300 mA. Check whether DC power supply or solar panels is ok, then check 'Test data'->'diL' value is about 40; 'Then check the leakage current sensor or circuit (the following picture). Checking test data needs using bigLCD. 2.Restart the inverter, if the error still exists, please contact your installer or LEDVANCE service.
F17	Three phase current, over-current fault	Hardly appear the code. Never ever happened so far.
F18	AC over current fault of hardware	1.Check AC sensor or detection circuit on control board or connection wire. 2.Restart the inverter or factory reset, if the error still exists, please contact your installer or LEDVANCE service.
F19	All hardware failure synthesis	Hardly appear the code. Never ever happened so far.

ERROR INFORMATION AND PROCESSING

Error code	Description	Ongrid -three phase
F20	DC over current fault of the hardware	1.Check whether solar panel output current is within the allowed range. 2.Check DC current sensor and its detection circuit. 3.Check if the inverter FW version is suitable for the hardware. 4.Restart the inverter, if the error still exists, please contact your installer or LEDVANCE service.
F21	DC leakage flow fault	Hardly appear the code. Never ever happened so far.
F22	Crash stop (if there is a stop button)	Contact your installer for help.
F23	AC leakage current is transient over current	1.This fault means the leakage current is above 30 mA suddenly. Check whether DC power supply or solar panels is ok, then check 'Test data'-> 'diL'value is about 40; Then check the leakage current sensor or circuit. Check test data needs using big LCD. 2.Restart the inverter, if the fault still exists, contact your installer or LEDVANCE service.
F24	DC insulation impedance failure	1.Check Vpe resistance on main board or detection on control board. Check PV panels is OK. Many times this issue is the PV problem. 2.Check whether the PV panel (aluminum frame) is grounded well and inverter is grounded well. Open the cover of inverter and then check the inside ground cable is fixed well on the shell. 3.Check if the AC/DC cable, terminal block are shorted to ground or the insulation is damaged. 4.Restart the inverter, if the fault still exists, contact your installer or LEDVANCE service.
F25	DC feedback fault	Hardly appear the code. Never ever happened so far.
F26	The DC busbar is unbalanced	1.Check whether the 'BUSN' cable or driver board power supply cable is loose. 2. Restart the inverter, if the fault still exists, contact your installer or LEDVANCE service.
F27	DC end insulation error	Hardly appear the code. Never ever happened so far.
F28	Inverter 1 DC high fault	Hardly appear the code. Never ever happened so far.
F29	AC load switch failure	Hardly appear the code. Never ever happened so far.
F30	AC main contactor failure	1.Check relays and AC voltage of relays. 2.Check relays driver circuit. Check if the software is not suitable for this inverter. (Old inverter not have relays detection function) 3. Restart the inverter, if the fault still exists, contact your installer or LEDVANCE service.
F31	Relay open circuit fault	1.At least one Relay can't be closed. Check relays and its driver signal. (Old inverter not have relays detection function) 2.Restart the inverter, if the fault still exists, contact your installer or LEDVANCE service.
F32	Inverter 2 dc high fault	Hardly appear the code. Never ever happened so far.
F33	AC over current	Hardly appear the code. Never ever happened so far.
F34	AC current over load	Hardly appear the code. Never ever happened so far.
F35	No AC grid	1.Check AC grid voltage. Check AC voltage detection circuit. Check if the AC connector in good condition. Check whether the AC grid is normal in voltage. 2. Restart the inverter, if the fault still exists, contact your installer or LEDVANCE service.

ERROR INFORMATION AND PROCESSING

Error code	Description	Ongrid -three phase
F36	AC grid phase error	Hardly appear the code. Never ever happened so far.
F37	AC three-phase voltage unbalance failure	Hardly appear the code. Never ever happened so far.
F38	AC three-phase current unbalance failure	Hardly appear the code. Never ever happened so far.
F39	AC over current (one cycle)	1.Check AC current sensor and its circuit. 2.Restart the inverter, if the fault still exists, contact your installer or LEDVANCE service.
F40	DC over current	Hardly appear the code. Never ever happened so far.
F41	AC Line W, U over voltage	Check the AC voltage protection setting. And Check if the AC cable is too thin. Check the voltage difference between LCD and meter.
F42	AC Line W, U low voltage	Check the AC voltage protection setting. Check the voltage difference between LCD and meter. Also need to check whether AC cables are all firmly and correctly connected.
F43	AC Line V, W over voltage	Check the AC voltage protection setting. And Check if the AC cable is too thin. Check the voltage difference between LCD and meter.
F44	AC Line V, W low voltage	Check the AC voltage protection setting. Check the voltage difference between LCD and meter. Also need to check whether AC cables are all firmly and correctly connected.
F45	AC Line U, V over voltage	Check the AC voltage protection setting. And Check if the AC cable is too thin. Check the voltage difference between LCD and meter.
F46	AC Line U, V low voltage	Check the AC voltage protection setting.
F47	AC Over frequency	Check the AC voltage protection setting.
F48	AC lower frequency	Check the AC voltage protection setting.
F49	U phase grid current DC component over current	Hardly appear the code. Never ever happened so far.
F50	V phase grid current DC component over current	Hardly appear the code. Never ever happened so far.
F51	W phase grid current DC component over current	Hardly appear the code. Never ever happened so far.
F52	AC inductor A, phase current DC current high	Hardly appear the code. Never ever happened so far.
F53	AC inductor B, phase current DC current high	Hardly appear the code. Never ever happened so far.
F54	AC inductor C, phase current DC current high	Hardly appear the code. Never ever happened so far.
F55	DC busbar voltage is too high	1.Check PV voltage and Ubus voltage and its detection circuit. If the PV input voltage exceeds the limit, please reduce the number of solar panels in series. 2. For Ubus voltage, please check the LCD display.

ERROR INFORMATION AND PROCESSING

Error code	Description	Ongrid -three phase
F56	DC busbar voltage is too low	1.It tells the PV input voltage is low and it always happens in the early morning. 2.Check PV voltage and Ubus voltage. When inverter is running, then showing F56, maybe Loss of driver or need update firmware. 3.Restart the inverter, if the fault still exists, contact your installer or LEDVANCE service.
F57	AC reverse irrigation	AC reverse irrigation.
F58	AC grid U over current	Hardly appear the code. Never ever happened so far.
F59	AC grid V over current	Hardly appear the code. Never ever happened so far.
F60	AC grid W over current	Hardly appear the code. Never ever happened so far.
F61	Reactor A phase over current	Hardly appear the code. Never ever happened so far.
F62	Reactor B phase over current	Hardly appear the code. Never ever happened so far.
F63	ARC fault	1.Check PV module cable connection and clear the fault; 2.Seek help from us, if can not go back to normal state.
F64	IGBT heat sink high temperature	1.Check temperature sensor. Check if firmware is suitable for the hardware. Check if the inverter is its right model. 2.Restart the inverter, if the fault still exists, contact your installer or LEDVANCE service.

Error codes and their solutions



SAFETY HINT:

If your string inverter has any of the fault information shown in Table above, and when you reset the machine and still don't solve the problem, please contact our distributor and provide the below details:

- Serial number of the inverter;
- The distributor/dealer of the inverter (if available);
- Installation date;
- The description of problem (include LCD error code and LED status indicator lights);
- Your contact details.

SPECIFICATION

Model	LT-3K/4K/5K/6K F1			
PV string Input data				
Max. PV Input Power (kW)	3.9	5.2	6.5	7.8
Max. PV Input Voltage (V)	1100			
Start-up Voltage (V)	140			
PV Input Voltage Range (V)	140 - 1100			
MPPT Voltage Range (V)	120 - 1000			
Full Load MPPT Voltage Range (V)	350 - 850			
Rated PV Input Voltage(V)	600			
Max.Input Short Circuit Current (A)	30 + 30			
Max. Operating PV Input Current (A)	20 + 20			
No. of MPP Trackers/No. of Strings per MPP Tracker	2 / 1 + 1			
Max. Inverter Backfeed Current To the Array	0			
AC output data				
Rated AC Output Active Power (kW)	3	4	5	6
Max.AC Output Apparent Power (kVA)	3.3	4.4	5.5	6.6
Rated AC Output current (A)	4.6 / 4.4	6.1 / 5.8	7.6 / 7.3	9.1 / 8.7
Max. AC Output Current (A)	5 / 4.8	6.7 / 6.4	8.4 / 8	10 / 9.6
Max. Output Fault Current (A)	8.8	11.6	14.6	17.4
Max. Output Overcurrent Protection (A)	47.7			
Rated Output voltage / range (V)	220 / 380, 230 / 400 0.85 Un-1.1 Un			
Grid Connection Form	3L + N + PE			
Rated Output Grid Frequency / range (Hz)	50 Hz / 45 Hz - 55 Hz, 60 Hz / 55 Hz - 65 Hz			
Power Factor Adjustment Range	0.8 leading - 0.8 lagging			
Total Current Harmonic Distortion THDi	< 3%			
DC Injection Current	< 0.5% In			
Efficiency				
Max.Efficiency	98.1%		98.2%	
Euro Efficiency	97.5%		97.6%	
MPPT Efficiency	> 99%			
Equipment protection				
DC Polarity Reverse Connection Protection	yes			
AC Output Overcurrent Protection	yes			
AC Output Overvoltage Protection	yes			
AC Output Short Circuit Protection	yes			
Thermal Protection	yes			
DC Terminal Insulation Impedance Monitoring	yes			
DC component monitoring	yes			
Ground fault current monitoring	yes			
Power Network Monitoring	yes			
Island protection monitoring	yes			
Earth Fault Detection	yes			
DC Input Switch	yes			
Overvoltage Load Drop Protection	yes			
Residual Current (RCD) Detection	yes			
Surge Protection Level	TYPE II (DC), TYPE II (AC)			

SPECIFICATION

Interface	
Communication Interface	RS485 / RS232
Monitor Mode	GPRS / WIFI / Bluetooth / 4G/LAN (optional)
Display	LCD + LED
General data	
Operating Temperature Range (°C)	-25 to + 60 °C, > 45 °C derating
Permissible Ambient Humidity	0 - 100%
Permissible Altitude (m)	4000 m
Noise (dB)	< 45 dB
Ingress Protection(IP)Rating	IP 65
Inverter Topology	Non-Isolated
Over Voltage Category	OVC I (DC) , OVC III (AC)
Cabinet Size (W*H*D) [mm]	283 × 463 × 178 (Excluding connectors and brackets)
weight [kg]	11
Warranty [year]	Standard 5 years, extended warranty
Type Of Cooling	Natural cooling
Grid Regulation	IEC 61727, IEC 62116, EN 50549
Safety EMC / Standard	IEC / EN 61000-6-1 / 2 / 3 / 4, IEC / EN 62109-1, IEC / EN 62109-2

SPECIFICATION

Model	LT-TK/8K/9K/10K/12K F1				
PV string Input data					
Max. PV Input Power (kW)	9.1	10.4	11.7	13	15.6
Max. PV Input Voltage (V)	1100				
Start-up Voltage (V)	140				
PV Input Voltage Range (V)	140 - 1100				
MPPT Voltage Range (V)	120 - 1000				
Full Load MPPT Voltage Range (V)	480 - 850				
Rated PV Input Voltage (v)	600				
Max. Input Short Circuit Current (A)	30 + 30				
Max. Operating PV Input Current (A)	20 + 20				
No. of MPP Trackers / No. of Strings per MPP Tracker	2/1 + 1				
Max. Inverter Backfeed Current To the Array	0				
AC output data					
Rated AC Output Active Power (kW)	7	8	9	10	12
Max.AC Output Apparent Power (kVA)	7.7	8.8	9.9	11	13.2
Rated AC Output current (A)	10.7 / 10.2	12.2 / 11.6	13.7 / 13.1	15.2 / 14.5	18.2 / 17.4
Max.AC Output Current (A)	11.7 / 11.2	13.4 / 12.8	15 / 14.4	16.7 / 16.0	20 / 19.2
Max. Output Fault Current (A)	20.4	23.2	26.2	29	34.8
Max.Output Overcurrent Protection (A)	47.7				
Rated Output voltage / range (V)	220 / 380, 230 / 400 0.85 Un - 1.1 Un				
Grid Connection Form	3L+N+PE				
Rated Output Grid Frequency / range (Hz)	50 Hz /45 Hz - 55 Hz, 60 Hz / 55 Hz - 65 Hz				
Power Factor Adjustment Range	0.8 leading - 0.8 lagging				
Total Current Harmonic Distortion THDi	< 3%				
DC Injection Current	< 0.5%In				
Efficiency					
Max. Efficiency	98.3%				
Euro Efficiency	97.8%				
MPPT Efficiency	99%				
Equipment protection					
DC Polarity Reverse Connection Protection	yes				
AC Output Overcurrent Protection	yes				
AC Output Overvoltage Protection	yes				
AC Output Short Circuit Protection	yes				
Thermal Protection	yes				
DC Terminal Insulation Impedance Monitoring	yes				
DC component monitoring	yes				
Ground fault current monitoring	yes				
Power Network Monitoring	yes				
Island protection monitoring	yes				
Earth Fault Detection	yes				
DC Input Switch	yes				
Overvoltage Load Drop Protection	yes				
Residual Current (RCD) Detection	yes				
Surge Protection Level	TYPE I I(DC), TYPE II (AC)				

SPECIFICATION

Interface	
Communication Interface	RS485 / RS232
Monitor Mode	GPRS / WIF I/ Bluetooth / 4G / LAN (optional)
Display	LCD + LED
General data	
Operating Temperature Range (°C)	-25 to +60 °C, > 45 °C derating
Permissible Ambient Humidity	0 - 100%
Permissible Altitude (m)	4000 m
Noise (dB)	< 45 dB
Ingress Protection(IP)Rating	IP 65
Inverter Topology	Non-Isolated
Over Voltage Category	OVC I (DC), OVC III (AC)
Cabinet Size (W*H*D) [mm]	283 × 463 × 178 (Excluding connectors and brackets)
weight [kg]	11
Warranty [year]	Standard 5 years, extended warranty
Type of Cooling	Natural cooling
Grid Regulation	IEC 61727, IEC 62116, EN 50549
Safety EMC / Standard	IEC / EN 61000-6-1 / 2 / 3 / 4, IEC / EN 62109-1, IEC / EN 62109-2

EU DECLARATION OF CONFORMITY

within the scope of the EU directives

- Electromagnetic compatibility 2014/30/EU (EMC)
- Low Voltage Directive 2014/35/EU (LVD)
- Restriction of the use of certain hazardous substances 2011/65/EU (RoHS)



